ERD CALCULATION

Due to the various different nipples on the market our published ERD numbers do not account for nipple height. To calculate ERD, the nipple head height x2 needs to be added to the listed number.

EXAMPLE:

R90 SL RIM ERD Listed as: 580++

580 + (nipple head height) + (nipple head height) = **ERD**



